


OLIVER BONAS


AROMA DIFFUSER



USE & CARE INFORMATION

COMPONENTS

FRONT VIEW



CARE INFORMATION

We hope you love your purchase, however if you aren't completely happy please retain your packaging to ensure its safe return.

Read all instructions before use

- For indoor use only
- Not for use in bathrooms or humid environments
- For adult use only, keep out of reach of children and pets
- Only use with the 24V DC adapter supplied
- Do not use if the cable is in any way damaged
- Do not attempt to open the electrical component
- Only for use with diluted essential oil
- Do not use when the water tank is empty
- Place on a level, protective surface
- Do not block the air inlet underneath
- Keep away from painted, polished and flammable materials
- Essential oils may stain or mark surfaces
- Wipe away any residue oil
- Essential oils are flammable, do not light and keep away from open flames
- Do not pour water into or close to the air outlet
- Make sure to unplug from the mains when refilling
- Do not cover the mist outlet
- Do not move the diffuser when in use

Retain this information for reference.

OLIVER BONAS LTD
Unit F, Davis Road Industrial Park
Chessington, Surrey, KT9 1TQ



INSTRUCTIONS

Step 1: Place diffuser on a flat surface and remove ceramic cover and cap.




Step 2. Turn upside down to connect DC adapter into diffuser.

Do not plug into mains until fully filled and assembled in case of any spillages.



Step 3. Turn back upright, placing on a flat and level surface. Fill a measuring cup with 90-100ml of water and add to water tank. Make sure not to exceed the max fill line. Add with 2-3 drops of essential oil.




Step 4: Replace cap and ceramic cover. Make sure both the cover and cap air outlet are aligned. Plug adapter into mains.



CLEANING

Always unplug the diffuser before cleaning. When emptying any excess water, ensure that poured from the draining side, as marked on the water tank. Clean inside regularly with a clean, soft, dry cloth to remove any impurities

OPERATIONS



MIST BUTTON

Press once
Power on, mister will operate for 30 minutes
Press twice
Mister will operate for 1 hour
Press three times
mister will operate for 2 hours
Press four times
mister will operate for 3 hours
Press five times
mister will power off

LIGHT BUTTON

Press once for white light
Press twice for red light
Press three times for blue light
Press four times for green light
Press five times for purple light
Press six times for yellow light
Press seven times for blue light
Press eight times for white light
Press nine times for light off